
Setting up Email Alerts for Camera and System Issues

Ocularis Recorder 5.0 has the ability to send emails when it detects an issue with cameras or the recorder itself. This document walks through the steps of setting this up and explains some of the options.



In the "General" section (3) check the "Activated" box and configure the necessary settings for the mail server that will be used. When complete, is test ermal can be sent by cicking the "Send test email" button which will be enabted once a System email is entered (see step 8 below).



The "General" section allows for the creation of Email Lists. These lists can be configured with email addresses and assigned to system events. When these events occur the addresses on the list will be notified (6). Any email list created will be listed under System Advertes (7). In the above image there is an example list called "IT Admins".



The 'Warm addresses' section (8) is where email addre displayed in the 'Email and FTP' section of an alarm.



The 'System addresses' section (9) is where email addresses are set for System event notifications. Note that at least one email address needs to be set here in order to use the 'Send test email in the 'SMTP' server' mentioned above.



In the 'General' section (12) settings related to event retention and what time the daily report email should be sent may be configured. This email will report the system events for the last 24 hours.

